




Grille Installation Instruction

Rev. 150116

Part#	GR03HFF30A	Application	03-09 Chevy Kodiak C4500-9500 Side Vent
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Screws	4	#8
	2	Speed Clips	4					

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the side vent from the vehicle	N/A
3	Using a die grinder cut out the center section of the side vent, removing all the honeycomb section. Smooth out the rough cut section of the vent, using a flat file.	N/A
4	Place the billet insert into the pocket of the vent. Center the billet insert, and then mark and drill into the plastic where the tabs of the billet insert line up.	N/A
5	Secure the billet insert to the side vent using the #8 screws and speed clips. The #8 screws will go through the billet insert tabs into the plastic, and the speed clips will be used as a nut to hold into place.	N/A
6	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!