

Grille Installation Instruction

Part#	GR03HFH44H Application		1978-1981 Chevy Camaro Lower Bumper							
Parts Lis	Item	Part Name	e QTY	Des	cription	ltem	Part Name	QTY	Description	
	t 1	Billet Grille	1	1 Aluminu		3	Kept Nut	3	10#	
	2	Thread stud	3	#10-24	× 11/4 ″	4	Z bracket	3		
Install Notes: Overlay \times Replacement $$ Drill \times Cut \times										
Step		Descri	ption			illustration				
	Identify the grille & hardware with parts list.									
	Thread the studs into the thread holes on the rear of the billet grille.									
	Fasten the Z brackets on the rear of the billet grille with the studs & kept nuts.				et	Z bracket, stud & nut				
4	Remove the OEM plastic grille by unfastening the OEM screws. And set aside the OEM screws, the screws will be reused.									

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Part#	GR03HFH44H	Application	1978-1981 Chevy Camaro Lower Bumper
5	Identify the 4 holes & U- cross plate at both sides Note: If necessary, cente the opening market & dr the plastic cross plate ac positions of the Z bracke	of the opening. For the billet grille into the billet grille into the billet grille into the billet into the the billet opening to the billet the billet opening to the billet	
6	Center the billet grille (w the opening and secure the OEM screws & u-clip removed on step4.	the billet grille with	Front There the OEM screw through the gap between the billets from front side
7	Installation completed	!!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!