

PATENT PRODUCT Grille Installation Instruction

Rev. 190101

| Part# | GR03HFJ04C/S/J | | | Ap | Application Fo | | For 198 | or 1986-1990 Chevy Caprice | | | | | |
|----------|---|------------------------|--|----------------|------------------|--------------------|-------------------------------|----------------------------|---|----------------------|----------------------|---|--|
| | | Item | Part Nam | е | e QTY De | | cription Ite | | Part Name | | QTY | Description | |
| Parts Li | ist | 1 | Billet Grille | | 1 Stainl | | ess steel | 3 | Screws | | 8 | 8×3/4" | |
| | | 2 Clip Nuts | | | 8 8# | | | | | | | | |
| nstall N | Note | es: Ov | verlay × | Re | placen | nent | √ D | rill | √ Cut | $\sqrt{}$ | | | |
| Step | Description | | | | | | | illustration | | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | | | | | | | | |
| 2 | Remove the grille shell from vehicle. Use a die grinder or an alterative tool to cut the inner grille work out. Make your cuts close to the inner edge (where the bars are molded to the main grille). Do not cut the six mounting tabs use to secure the grille to the vehicle. File or sand any youth edges smooth. When finished the grille should look like the diagram below. The shadowed area illustrates what material needs to be removed. | | | | | | | | | | | | |
| | 10 | 1 | | | | | lei | | | | | 10 | |
| 3 | insi the fast | ide radio grille sl | us of the factory hell. Drill a 1/8" billet, a light coa | grille hole | in the b | ottom c mark. S | corners. Hold Secure the b | d the bille billet inse | et insert firmly in ort to the shell u | n place; sing the | Mark eac #8 screw | This will help clear h mounting tab hole is and flat nuts. Befirille to hide the sand | |
| 4 | Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten. | | | | | | | | | | | | |
| 5 | Inst | tallation | completed!!! | | | | | | | | | | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!