



PATENT PRODUCT

Grille Installation Instruction

Rev. 20220301

Part#	C86006C/J/S	<i>Application</i>	For 1998-2003 Chevy Camaro
--------------	-------------	--------------------	----------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	2	Screws	4	8#×1"

Install Notes: Overlay Replacement Drill Cut

Step	Description	Illustration
1	Identify the grille & hardware with parts list.	
2	Run a line of 1/8" tape around the inside perimeter of the cavity on black it out with semi-gloss black.	
3	Center the grille in the opening; mark and drill with a 1/8" bit for the holes in the four tabs.	
4	Secure with the fasteners provided.	
5	Installation completed.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!