


| | | | |
|--------------|------------------|--------------------|---|
| Part# | GR03IEG43 A/H | <i>Application</i> | For 2006-2013 Chevy Impala /2006-2007 Chevy Monte Carlo /2014-2016 Chevy Impala Limited Model Only |
|--------------|------------------|--------------------|---|

| | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|-------------------|------|---------------|-----|-------------|------|-----------|-----|-------------|
| Parts List | 1 | Billet Grille | 2 | Aluminum | 3 | Tabs | 4 | |
| | 2 | Slotted Stud | 4 | 6-32×1" | 4 | Keq Nuts | 4 | 6-32 |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | |
| 3 | Center the billet grille into the opening of the factory grille shell. Screw studs inside the hole behind of grille. Insert billet grille on the opening of factory shell from front. Push the studs past through honey comb of factory grille. | |
| 4 | Put the tabs provided behind factory honey comb and screw nut on the bolt after tab. | |
| 5 | Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten. | |
| 6 | Reinstall the black plastic cover which was removed in step 2. | |
| 7 | Installation completed!!! | |

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!