


| | | | |
|-------|------------------|-------------|---|
| Part# | GR03IEG44 A/H | Application | For 2006-2013 Chevy Impala With Fog Light /2014-2016 Chevy Impala Limited Model Only With Fog Light |
|-------|------------------|-------------|---|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-------------|------|---------------|-----|---------------|
| | 1 | Billet Grille | 3 | Aluminum | 3 | Slotted Studs | 10 | 6-32 × 1 1/2" |
| | 2 | Nuts | 10 | 6-32 | 4 | Flat Tabs | 10 | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | |
| 3 | Center the billet grille into the opening of the factory grille shell. Screw studs inside the hole behind of grille. Insert billet grille on the opening of factory shell from front. Push the studs past through honey comb of factory grille. | |
| 4 | Put the tabs provided behind factory honey comb and screw nut on the bolt after tab. | |
| 5 | Make sure the grille is centered and tighten the fasteners, but do not over-tighten. | |
| 6 | Reinstall the black plastic cover which was removed in step 2. | |
| 7 | Installation completed!!! | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!