

6

Installation completed!!!

Grille Installation Instruction

Rev. 190501

 Part#
 GR03/EG74 A/H
 Application
 For 2007-2010 Chevy Silverado 3500 HD /2007-2010 Chevy Silverado 2500 HD

		A/H		Chevy Silverado 2500 HD									
Parts List		Item	Par	t Name QTY		Description		Item	Part Name		QTY	Description	
		1	Billet G	Grille	2	2 Aluminum		3	Studs		6	10-24×2″	
		2	Flat Ta	abs	6			4	Nylon Lock Nuts		6	10-24	
Install Notes: Overlay $\boxed{\hspace{1em}}$ Replacement $\boxed{\hspace{1em}}$ Drill $\boxed{\hspace{1em}}$ Cut $\boxed{\hspace{1em}}$													
Step	Description							illustration					
1	Identify the grille & hardware with parts list.							89171					
2	Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.												
3	Thread a stud in each nut welded to the grille.												
4	From the rear, place a tab on each screw. Now thread a nut on each screw.												
5	Mak	Make sure the insert is centered and tighten the hardware.											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!