


Part#	GR03IEG74 A/H	<i>Application</i>	For 2007-2010 Chevy Silverado 3500 HD /2007-2010 Chevy Silverado 2500 HD
--------------	------------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	2	Aluminum	3	Studs	6	10-24×2"
	2	Flat Tabs	6		4	Nylon Lock Nuts	6	10-24

Install Notes:	Overlay <input checked="" type="checkbox"/>	Replacement <input type="checkbox"/>	Drill <input type="checkbox"/>	Cut <input type="checkbox"/>
-----------------------	---	--------------------------------------	--------------------------------	------------------------------

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.	
3	Thread a stud in each nut welded to the grille.	
4	From the rear, place a tab on each screw. Now thread a nut on each screw.	
5	Make sure the insert is centered and tighten the hardware.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!