







Grille Installation Instruction

Rev. 120801

Part#	GR03LEA73H	Application	11-14 Chevy Silverado HD Rivet Black Stainless Steel Wire Mesh Replacement Grille
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	4	Stainless steel	4	Lock Nut	62	10-24
	2	Phillips Screw	27	10-24x1/2"	5	Small Metal Brackets	2	20x19mm
	3	L Brackets	27	90°	6	Big Metal Brackets	6	50x19mm

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Optional: Using factory instructions, remove the entire front grille shell	N/A
4	Remove the OEM black plastic grille from the shell.	
5	Position the upper and lower pieces of Grille onto grille shell cavity. Position the two center pieces of Grille onto grille shell cavity	
6	Secure the stud to the threaded holes on the rear of the grille.	N/A
7	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.	N/A
8	Secure grille using the flat tabs and lock nuts from the back side of the OEM grille shell.	
9	Make sure the grille is centered and tighten the fasteners.	N/A
10	Reinstall the black plastic cover which was removed in step 2, now installation completed!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!