





Grille Installation Instruction

Rev. 120801

Part#	GR03LEA77H	Application	2014 Chevy Silverado 1500
-------	------------	-------------	---------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless steel	2	L Brackets	22	
	3	Phillips Screw	22	M4*15mm	4	Flange Nuts	44	M4

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Optional: Using factory instructions, remove the entire front grille shell	
4	Remove the OEM black plastic grille from the shell.	
5	Position the Grille onto Grille onto grille shell cavity.	
6	Mark locations for drilling on the shell through the holes of L Brackets..Then remove the brackets and drill holes on these locations. Attach the Grille to the shell by inserting the screws through the tabs of L Brackets and holes on the shell, secure them with Flange Nuts provided	
7	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.	
8	Make sure the grille is centered and tighten the fasteners.	N/A
9	.Reinstall the black plastic cover which was removed in step 1, now installation completed!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!