

## Grille Installation Instruction

Part#	(	GR03LFD51H		pplicati	ation 200		007-2012 Chevy Tahoe AVALANCH Main Upper							
		ltem	Par	t Name	QTY	D	escrip	tion	Item	Part Name	QTY	Description		
Parts Lis		1	Mesh Grille		1	Stainle	ess stee		4	Flat Tab 1	4	1		
	51	2	Screw stud		8	10-24	×2″	,		Flat Tab 2	2	1		
		3	Lock I	Nut	8	10-24			6	/	1	1		
Install No	I Notes: Overlay √ Replacement							× Drill × Cut ×						
Step				Descrip	tion					illustr	ation			
1	Identify the grille & hardware with parts list.													
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.													
3	Secure the stud to the threaded holes on the rear of the grille. $4-32 \times 2"$ $4-32 \times 2"$ $4-32 \times 2"$													
4	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.									VI grille shell.				
5	Secure grille using the flat tabs and lock nuts from the back side of the OEM grille shell.				ts	Flat Tab 1								

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!



## Grille Installation Instruction

Part#	GR03LFD51H	Application	20	07-2012 Chevy Tahoe AVALANCH Main Upper				
6	Make sure the grille is c the fasteners.	entered and tighte	n	N/A				
7	Reinstall the black plast removed in step 1.	ic cover which wa	5	N/A				
8	Installation completed!!!			N/A				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!