



Part#	D45169N	Application	For 2009-2012 Dodge Ram 1500
-------	---------	-------------	------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1#	Rivet Grille	1	Stainless steel	4#	L Brackets	6	90°
	2#	Phillips Screws	16	10-24X1/2"	5#	L Brackets A	8	70°
	3#	Flange Nuts	32	10#	6#	L Brackets B	2	70°

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop Hood, remove plastic shroud at the top and set fasteners aside.	
3	Optional:Using factory instructions, remove the entire front grille shell (as pictured in all Figures).	
4	Attach the six 90°L Brackets to the screws on the bottom of the grille, secure them with flange nuts.	
5	Attach the eight 70°L Brackets A to the screws on the top of the grille, secure them with flange nuts.	
6	Attach the two 70°L Brackets B to other screws of the grille, secure them with flange nuts.	
7	Position the Grille onto grille shell cavity.	
8	Mark locations for drilling on the shell through the holes of L Brackets. Then drill holes on those locations.	
9	Attach the Grille to the shell by inserting the screws through the tabs of L Brackets and holes on the shell;secure them with Flange Nuts provided (Figure 3).	
		
7	Reinstall the plastic shroud with the fasteners removed in Step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!