

PATENT PRODUCT Grille Installation Instruction

Rev. 190501

Part#		GR04FEI19 C/J/S		For 2013-2018 Ram 1500 Honeycomb Style Only Main Upper								
		em	Part Na	me	QTY Descrip		otion	ltem	Part Name	QTY	Description	
Parts List		1	Billet Grille		4 Stainless st		eel	3	Toggle Nut	12	6# -32	
		2 Bolt			12	6#-32x1.5"						
Install	Notes	s: 0	overlay $$ F		Replacement ×		D	ill 🖂	Cut	×		
Step		Description					illustration					
1	Identify the grille & hardware with parts list.											
2	Optional: remove the plastic cover on the bottom of the OEM front bumper, which will allow access to the rear of the OEM grille											
3	Insert the screws into the weld tab hole from front side of the billet grille.							Picture for reference only. This is not actual grille. Weld tab Screw Toggle nut				
4	Center the billet grille onto the OEM grille. Press & insert the toggle nuts on to the rear of the OEM grille through the gap between the horizontal bars.											
5	Secure the grille using the toggle nuts and screws from the front side of the billet grille with a screw driver.							Toggle Nut				
6	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!