



PATENT PRODUCT




Grille Installation Instruction

Rev. 120515

Part#	GR04FFH83C	Application	For 2009-2010 Dodge Ram 1500 Only For Sport Model Lower Bumper
--------------	------------	--------------------	--

	Item	QTY	Part Name	Description	Item	QTY	Part Name	Description
Parts List	1	1	Billet Grille insert	Stainless steel	3	2	Screw	8#x1 1/4"
	2	2	Flat Nut	8#	4			

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	The first step of the installation is to take the billet grille and insert it into the plastic section of the bumper. Next take a drill and drill through the 2 small brackets (Fig1), with holes in them on the back side of the billet and through the black plastic of the bumper.	 <p style="text-align: right;">(Fig1)</p>
3	Insert a #8 screw through the small bracket with the hole in it and through the black plastic section of the bumper. From behind the bumper install a flat nut on the back side of the screw and tighten with a Phillips screwdriver. (Fig2) Repeat this on the other small bracket that is welded on the bracket of the billet.	 <p style="text-align: right;">(Fig 2)</p>
4	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!