

Grille Installation Instruction

Rev. 190501

Part#	GR04GFE19T/H	Application	For 2007-2010 Dodge Avenger SXT Not For V6
-------	--------------	-------------	--------------------------------------------

		Item Part Name		QTY	Y Description		Item	Part Name	QTY	Description		
Parts Li	ist	1	Billet Grille	3	Stainless steel		3	Screws	10	6-32×1″		
		2	"U" Tabs 10				4	Nylon Lock Nuts	10	6-32		
Install Notes: Overlay $\boxed{\hspace{1em}}$ Replacement $\boxed{\hspace{1em}}$ Drill $\boxed{\hspace{1em}}$ Cut $\boxed{\hspace{1em}}$												
Step	Description					illustration						
1	Identify the grille & hardware with parts list.											
	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
	Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.											
4	Thread a screw in each nut welded to the grille. From the rear, place a "U" tab on each screw. Now thread a nut and on each screw.											
5	Make sure the insert is centered and tighten the hardware.											
6	Reinstall the black plastic cover which was removed in step 2.											
7	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!