




# Grille Installation Instruction

Rev. 180301

Part#	GR04GFH77T/H/C	Application	<b>For 2011-2018 Dodge Journey Only For SE Model</b>					
-------	----------------	-------------	--	--	--	--	--	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	3	Screws	4	6-32 × 1"
2	Flat Tabs	4		4	K-Lock Nuts	4	6-32	

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood) , Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still Unable to access the rear, remove the grille shell and reattach after installation.	
3	Hold the grille insert up to the opening of the factory shell, and make sure that it is centered in the grille shell.	
4	Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut on each screw.	
5	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!