









Part#	GR04GFI10T	2011-2012 Dodge Charger	1PC Style Main Upper
Step 4: Grille Installation	Step4-1:Secure t the rear of the grid	4-32×1" 4-32×3" he sud to the threaded holes on ille.	Step4-2:Center the grille into the opening of the factory grille shell,Be sure the studs are through the OEM grille shell.
	Shell, Insert Flang	A short studs on the Grille ge Brackets to so it latches onto the Shell and thread a Lock Nut in	Step4-4:Place back the Factory Grille over the Grille Shell.
		Flat washers Around the son the Grille Shell and thread be.	Step4-6: Place back the Bumper Filler and re-install the 3 Screws along the bottom of the Factory Grille.
	Step4-7: Re-Asse bolts.	emble Bumper Support, Clips and	



Part#	GR04GFI10T	2011-2012 Dodge Charger 1PC Style Main Upper
Installation completed!!		