




Grille Installation Instruction

Rev. 180901

Part#	GR04HEC19A/H	Application	For 2006-2008 Dodge Ram 1500 Sport Tow Hook Must Be Removed
-------	--------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	6	Screws	4	8×1"
	2	U-Nuts	4	8#	7	Hex Bolts	2	1/4" -20×3/4"
	3	Short Z Brackets	2		8	Washers	2	1/4"
	4	Long Z Brackets	2		9	Lock Washers	2	1/4"
	5	Nuts	2					

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood and remove the factory tow hooks with a 9-16" (or 15mm) wrench / socket. Attach the short Z brackets to the inside bolt hole using the factory tow hook bolts .	
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
4	Attach the two longer Z brackets to the bumper; these attach to factory holes along the bottom of the bumper. Use the 1/4-20 bolts, nuts and washers.	
5	Slide a u-nut onto the other end of the mounting brackets. Center the grille into the opening (The small mounting tabs sit towards the bottom of the opening). Attach the grille using the #8 screws.	
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!