



PATENT PRODUCT Grille Installation Instruction

Rev. 20211201

Part#	D85319C&J&S	Application	For 2006-2008 Dodge Ram 1500 Sport Tow Hook Must Be Removed
--------------	-------------	--------------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	#1	Billet Grille	1	Stainless Steel	#6	Screws	4	8×1"
	#2	U-Nuts	4	8#	#7	Hex Bolts	2	1/4"-20×3/4"
	#3	Short Z Brackets	2		#8	Washers	2	1/4"
	#4	Long Z Brackets	2		#9	Lock Washers	2	1/4"
	#5	Nuts	2					

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood and remove the factory tow hooks with a 9-16" (or 15mm) wrench / socket. Attach the Short Z Brackets to the inside bolt hole using the factory tow hook bolts.	
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
4	Attach the (2) Longer Z Brackets to the bumper; these attach to factory holes along the bottom of the bumper. Use the 1/4-20 Hex Bolts, Nuts, Lock Washers and Washers.	
5	Slide a U-Nut onto the other end of the mounting brackets. Center the grille into the opening (The small mounting tabs sit towards the bottom of the opening). Attach the grille using the #8 Screws.	
6	Make sure the insert is centered and tighten the hardware.	
7	Reinstall the plastic shroud with the fasteners removed in Step 2.	
8	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!