

PATENT PRODUCTGrille Installation Instruction

Rev. 190901

Part#	GR04HEE40 C/J/S Application For 2019-2020 Ram 1500 Laramie/Lone Star/Big Horn/Tradesman Main Upper								ne Star/Big		
		Item	Part	Name	QTY	Description	Item	Part Name	QTY	Description	
Parts L	iet	1	Billet Grill	е	1	Stainless steel	4	Bolts	4	10-24x1/2"	
i aits L	ıσι	2 Lock Nut		ts 12		10-24	5	Plate	2		
		3	"C" Bracke	t	8						
Install Notes: Overlay X Replacement V Drill X Cut X											
Step	Description						illustration				
1	Atta	Identify the grille & hardware with parts list. Attach (2)plates to grille using bolts and lock nut. (2)10-24x1/2" Bolts (2)10-24 Lock Nuts									
2	Turn off engine, chalk tires with stop block, open the hood and disconnect the battery. The OEM Factory Grille will have to be removed. Begin grille removal by prying free all the Push Pin Retainer Clips (x12) to remove the radiator cover. (Fig 1)										
3	With the Radiator Panel Cover removed, Identify and remove the (x18) screws that secure the top trim/grille frame. (Fig 2-5)										
Fig 1 Fig 2 Fig 3 Fig 4 Fig 5											

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCTGrille Installation Instruction

Rev. 190901

AUT	TO PARTS SPECIALIST INC.	Ornic		Rev. 190901				
Part#	GR04HEE40 C/J/S	Application	For 2019-2020 Ram 1500 Larar Horn/Tradesman Main Upper	nie/Lone Star/Big				
4	Remove the (x4) screw from the front of the wheel well. Pull back the inner wheel well liner to access the front bumper / fender panel support mount. (Fig 6)							
5	Pull and remove the (front bumper / fender panel support mount) bolt as seen in Figures 8 & 9. (Fig 7-8)							
6	Repeat on opposite side.							
Fig 6		Fig	Fig 8					
7	Separate the Vehicle's Front Bumper Fascia from the Front Fender. You may need to coax free by pulling the fascia panels pushing on the fender.(Fig 9-10)							
8	Remove the (x3) bolts as seen in Figure # 12. Repeat on opposite side. (Fig 11)							
	Fig 9		Fig 10 Fig 11					
9			v be free to remove. Set it face down on a soft pad ving the screws as seen in Figure #13 (Fig 12-13)	ded surface Separate the OEM				
10	With the OEM Factory Grille fully disassembled, set aside, and take the OEM Grille Plastic Mounting Shroud and position over and onto new Replacement Grille. Secure in place with the provided "C" Bracket the 10-24 Nylon Nuts. The Replacement Grille should now be ready for installation. (Fig 14)							
11	Take the assembled g	rille component ar	nd put into place to install onto vehicle. (Fig 15)					

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCT

Grille Installation Instruction

Rev. 190901

For 2019-2020 Ram 1500 Laramie/Lone Star/Big GR04HEE40 Application Part# C/J/S Horn/Tradesman Main Upper Fig 14 Fig 13 Secure the grille to vehicle by screwing the bolts that were removed in Step #8 Step #3. (Fig 16) 12 Re-Install the bumper fascia panels as seen in Figure #18. Attach the and secure the front fender to bumper fascia panel in 13 the reverse order as they were removed. Re-Install the Vehicle's Factory Top Trim Piece. Re-Install the Vehicle's Radiator Cover Panel. (Fig 17-20) Fig 19 Fig 20 14 Installation completed!!!

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!