

Grille Installation Instruction

Rev. 141001

Part#		GR(04НЕЈ37С	Applio	cation	For 2	2005-	2007	Dodge M	agnum Exce	pt SR	Т8	
	Ite	em	Part Na	me	QTY	Descrip	otion	Item	Par	t Name	QTY	Description	
Parts Lis	st	1	Billet Grille		4	Stainless	steel	3	Truss Head T	apping Screws	16	8#	
		2	Speed Nuts		16	8×3/4"							
Install Notes: Overlay X Replacement V Drill V Cut X													
Step	Description i						illustration						
1	Identify the grille & hardware with parts list.												
2	Remove both plastic shrouds from the fill area of the grille shell and core support. Remove the push pins from the top of the vehicle shell. See figure 2.								e vehicles grille				
4	Pull back the grille shell slightly from the vehicle to access behind the grille shell. Next remove the two fasteners from both sides of the black section of the grille shell.						5	attac bum	Remove the final screws.(One on each side) that attaches the black center section of the grille shell to the bumper section. Once these have been removed pull each of the black grille shell section from the grille shell.				
6	There are four tabs in each openings of the grille shell; you will use these tabs to secure each billet inset. Note: When installing each billet insert you will install flush into the grille shell. To install you will pull the grille shell slightly towards you; loading the billet inserts from behind the grille shell. The grille shell will flex forward a little but use caution when doing so. Also the spacing is very limited so patient.												

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 141001

Part#	GR04НЕЈ37С	Application	For 2005-2007 Dodge Magnum Except SRT8						
	Identify each billet insert to its appropriate opening. Starting with the lower two billet inserts, place each into its opening, center the billet then markand drill a pilot hole for a #8 screw to attach. You may place e speed clip over the plastic grille shell tab or use the speed clip as a nut. Secure the lower billet inserts place, and then repeat this step to install the two upper inserts.								
7									
8	Make sure the billet grille is centered and tighten the fasteners.								
9	Installation completed!!!								

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!