




# Grille Installation Instruction

Rev. 190501

|              |                          |                    |                                      |
|--------------|--------------------------|--------------------|--------------------------------------|
| <b>Part#</b> | <b>GR04HEJ74<br/>A/H</b> | <b>Application</b> | <b>For 1999-2001 Dodge Ram Sport</b> |
|--------------|--------------------------|--------------------|--------------------------------------|

| Parts List | Item      | Part Name     | QTY | Description | Item | Part Name                 | QTY | Description |
|------------|-----------|---------------|-----|-------------|------|---------------------------|-----|-------------|
|            | 1         | Billet Grille | 4   | Aluminum    | 3    | Truss Head Tapping Screws | 16  | 8×3/4"      |
| 2          | Clip Nuts | 16            | 8#  |             |      |                           |     |             |

Install Notes: Overlay  Replacement  Drill  Cut

| Step | Description  | illustration   |
|------|--|--|
| 1    | Identify the grille & hardware with parts list.  |  |
| 2    | Remove stock grille shell assembly from truck. Cut and remove factory grille clips out from shell.                     |  |
| 3    | Open box packaged with 4 pieces billet grilles inside. Insert one piece into one shell opening ring matching in shape. |  |
| 4    | Mark location on where the shell will be drilled according to the hole of the tab on billet grille.                    |  |
| 5    | Drill 3/16" hole on the 4 sites marked on the shell.   |  |
| 6    | Tighten grille with Phillips screw and clips provided.   |  |
| 7    | Done same steps to other 3 billet grilles.   |  |
| 8    | Make sure the billet grille is centered and tighten the fasteners.   |  |
| 9    | Installation completed!!!  |  |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!