

## Grille Installation Instruction

Rev. 190901

Part#	GR04LEI86HApplicationFor 2013-2017 Ram 1500 Not For Rebel/2018 Ram 1500 Not For Rebel & Sport & Laramie Longhorn & Laramie Limited/2019 Ram 1500 Only For Classic									
		ltem	Part Nam	e QTY	Desc	ription	Item	Part Name	QTY	Description
Parts Lis	st	1	Rivet Grille	1	Stainless	steel	4	L Brackets	1	20*30mm
		2	S Brackets	ackets 14 I Brackets 1 40*19mm			5	Flange Nut	16	M4
		3	Metal Brack							
Install Notes: Overlay $\times$ Replacement $$ Drill $$ Cut $$										
Step	Description				illustration					
1	Identify the grille & hardware with parts list.									
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.									
3	<b>Optional:</b> Using factory instructions, remove the entire front grille shell, cut cross bar of OEM grille use the die grinder and sanding the cut place.									
4	Attach S Brackets to the screws on the grille, secure them with flange nuts. Drill the mounting hole if it's necessary.									
5	Position the Grille onto grille shell cavity.									
Attach the Grille to the shell by inserting the screws through the holes of S Brackets and the holes on the shell, and then secure them with Flange Nuts provided. Use 20*30mm "L" Bracket										
6	Use 40 19mm Metal Bracket									
7	Reinstall the plastic shroud with the fasteners removed in Step 2.									
8	Installation completed!!!									

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!