

2

Pop hood, remove the black plastic cover (on top of

access to the rear of the grille shell.

OEM grille / front panel) from vehicle. This will allow N/A

PATENT PRODUCT Grille Installation Instruction

Rev 150116

AUTO PARTS SPECIALIST INC.								Nev. 150110	
Part#	GR06FEB39A		Applicati on 98-00 For		ord Rar	ger 2WD Main Upper			
	It	tem	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts Li	st	1	Billet Grille	2	Aluminum	3	Nuts	4	10-32
		2	Screws	4	6-32×2″	4	Flange Brackets	4	
Install Notes: Overlay Replacement ×							× Cut ×		
Step	Description					illustration			
1	Identify the grille & hardware with parts list.					1			

Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on N/A 3 the front of the grille. Be sure the bolts are through the OEM grille shell. Secure billet grille using the nuts from the back side N/A 4 of the OEM grille shell. Make sure the billet grille is centered and tighten 5 N/A the fasteners. Reinstall the black plastic cover which was removed N/A 6 in step 2. 7 Installation completed!!! N/A

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!