



PATENT PRODUCT

Grille Installation Instruction

Rev. 20230501

Part#	F65290C&J&S	Application	For 2011-2014 Ford Edge
--------------	-------------	--------------------	-------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	#1	Billet Grille	1	Stainless Steel	#3	Toggle Nuts	3	6#
	#2	Bolts	3	6#-1.5"				

Install Notes: Overlay ☒ Replacement ☐ Drill ☒ Cut ☐

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.	
3	Insert the screws into the weld tab hole from front side of the billet grille.	<p>picture for reference only; this is not actual grille</p> <p>Weld tab Bolt Toggle nut</p>
4	Hold the grille against the OEM grille shell, center and mark (2) holes for drilling. Remove grille and drill holes according to your marks.	
5	Center the billet grille onto the OEM grille. Secure with the toggle nuts on to the rear of the OEM grille.	
		<p>Drill (1) Hole</p> <p>(3) Bolts (3) Toggle Nuts</p> <p>Drill (1) Hole</p>
6	Make sure the insert is centered and tighten the hardware.	
7	Reinstall the plastic shroud with the fasteners removed in Step 2.	
8	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!