


Part#	GR06FED94A/H	Application	For 2000-2003 Ford Taurus
-------	--------------	-------------	---------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Screws	4	8#×1 1/4"
	2	Clip Nuts	4	8#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the grille shell from your vehicle, unless you have enough room to work from the back of grille shell.	
3	Remove the plastic package and take out the new billet grille, test it fit a way for grille shell.	
4	Place the billet grille into the opening grille shell, it overlay factory grille shell honey comb, center it.	
5	Take the screw and push it into billet grille weld tab hole, through honey comb then place the clip nut from back of grille shell.	
6	When all the screws be screwed, adjust billet grille center, you tight each screw. Repeat this step for other billet grille. Finish all installation.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!