




Grille Installation Instruction

Rev. 191101

Part#	GR06FEE28A/H	Application	For 2007-2010 Ford Explorer Sport Trac Not For Adrenalin
-------	--------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Aluminum	4	Screw	8	8#x3"
	2	Flat Tabs	4		5	U-Nut	8	8#
	3	Flat Tabs	4					

Install Notes: Overlay ☒ Replacement ☐ Drill ☐ Cut ☐

Step	Description	Illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Remove grilles from box and test fit the grilles first to identify the top grille from the bottom grille. They will only fit in one direction correctly.	
4	Place one screw through each of the welded tabs on the billet grille.	
5	Place a U-clip nut over the hole on the flat tab.	
6	Where the screws come through the grille shell, place a tab in align with the screw and tighten. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. DO NOT OVER TIGHTEN SCREWS.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!