




Grille Installation Instruction

Rev. 190301

Part#	GR06FEG15A/H	<i>Application</i>	For 2003-2006 Ford Expedition
--------------	---------------------	--------------------	--------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	U- Clip Nuts	6	8#
2	Tabs	6		4	Truss Head Tapping Screws	6	8×2"	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the filler from panel between the grille shell and core support.	
3	Remove the factory Ford emblem from grille.	
4	Slide the U-clip nuts onto aluminum tabs.	
5	Center the billet grille over the factory grille insert. Insert a screw through top center mounting hole into an aluminum tab on backside of factory grille. Repeat for each mounting tab.	
6	Re-center the billet grille. Turn the tabs vertical and tighten.	
7	Reinstall the filler panel.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!