




PATENT PRODUCT Grille Installation Instruction

Rev. 20200901

| | | | |
|--------------|-------------|--------------------|--|
| Part# | F65738C&J&S | Application | For 1997-1998 Ford Expedition With Logo Show Not For Bar Style Model |
|--------------|-------------|--------------------|--|

| | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|-------------------|------|---------------|-----|-----------------|------|---------------------------|-----|-------------|
| Parts List | #1 | Billet Grille | 1 | Stainless Steel | #3 | Truss Head Tapping Screws | 4 | 8# x 2" |
| | #2 | U-Clip Nuts | 4 | 8# | #4 | Flat Tabs | 4 | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|--|--|
| 1 | Identify the grille & hardware with parts list. | |
| 2 | Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual. | |
| 3 | Install the U-clip nuts onto the tabs as shown. |  |
| 4 | Secure billet grille using the U-Clip Nuts, Truss Head Tapping Screws and Flat Tabs from the back side of the grille shell. | |
| 5 | Make sure the insert is centered and tighten the hardware. | |
| 6 | Reinstall the plastic shroud with the fasteners removed in Step 2. | |
| 7 | Installation completed. | |

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!