


<b>Part#</b>	F66658C-J	<i>Application</i>	<b>For 08~10 Ford Van Fullsize / Econoline Van – Billet Grille</b>
--------------	-----------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	6	Stainless steel	3	Truss Head Screws	12	6-32 × 1"
	2	Flat Tabs	12		4	K- Lock Nuts	12	6-32

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Center the billet grille into the opening of the shell, and place the screws through the holes of the tabs welded to the rear of the billet grille, then secure it using the tabs and k- lock nuts from the back.	N/A
4	Be sure the factory grille is centered, tighten all the hardware but do not over-tighten	N/A
5	Reinstall the black plastic cover which was removed in step 2.	N/A
6	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!