

## PATENT PRODUCT

Grille Installation Instruction

Rev. 180701

Part#	GR06FFH2 7S		Applicatio		ion X	For 2011-2016 Ford F-250 /F-350 / F-450 /F-550 SD XLT/Lariat/King Ranch Will Not Fit Base Model XL With Black Utility Grille							
	Item		Part Name		ne	QTY Des		ription	Item	Part Name		QTY	Description
Parts Li	ist 1		Billet Grille		4 Stainless st		ss steel	3	Bolt		8	6-32×1.5″	
	2 Toggle			Nut		8 6-32							
Install N	lote	s: Ov	verlay	$\checkmark$	Replacement		ment	× C	Drill ×	< l	Cut ×		
Step	Description									illustr	ation		
								li li					
1	Identify the grille & hardware with parts list.						UUU	-			=	-	
								-			-		
	Remove the factory grille from the vehicle. There are four 10mm bolts along the top of the grille under the hood (Fig 1) that need to be removed and a small plastic clip on the right corner that needs unclipped (Fig 2). The top of the grille will be loose, pull the bottom out until the latches pop loose and remove the grille, if the latches are tight you can use a flat screwdriver by reaching down behind the back of the factory grille and pressing the latches in with the screwdriver while pulling the grille forward.												
2	loos scre	e, pull wdrive	the botto r by read	om out ching c	until th	ne latche	es pop loo	ose and rei	move the	grille, if t	he latches	are tight you	i can use a flat
2	loos scre pulli With with shor	e, pull wdrive ng the the gr the fro rter bille	the botto r by read grille for rille rem ont side ets go ir	om out ching c ward. oved f facing n the n	until th lown b rom th up. Ta niddle s	e latche ehind th e vehicle ke one o side ope	e back of e you car of the bille	n now insta et grilles a e longer b	move the y grille ar all the fo nd place illets go i	grille , if t ad pressin ur billet gr it into the in the top	the latches the latches illes. Place appropriat and botton	the factory opening in openings).	i can use a flat
	loos scre pulli With with shoi over	e, pull wdrive ng the the gr the fro rter bille	the botto r by read grille for rille rem ont side ets go ir	om out ching c ward. oved f facing n the n	until th lown b rom th up. Ta niddle s	e latche ehind th e vehicle ke one o side ope	es pop loo e back of e you car of the bille enings, the Secure bi	n now insta et grilles a e longer b	move the y grille ar all the fo nd place illets go i	grille , if t id pressin	the latches the latches illes. Place appropriat and botton	the factory opening in openings).	a can use a flat e screwdriver while grille on a workbench the factory grille ( the Turn the factory grille
3	looss scree pulli With shor over (Fig	e, pull - ewdrive ng the n the gr the fro rter bille r so you 3)	the bottor r by read grille for rille rem ont side ets go ir u have a	om out ching o ward. oved f facing n the n access	until the	e vehicle ke one o side ope back.	es pop loo e back of e you car of the bille enings, the Secure bi	n now insta et grilles a e longer b	move the y grille ar all the fo nd place illets go using the	grille , if t d pressin ur billet gu it into the n the top toggle nu	Fig 3	the factory opening in openings).	a can use a flat e screwdriver while grille on a workbench the factory grille ( the Turn the factory grille
3 Fig 1	loos scree pullii With with shou over (Fig	e, pull - ewdrive ng the n the gr the fro r so you 3)	the bottor r by read grille for rille rem ont side ets go ir u have a the bille	om out ching c ward. oved f facing n the n access	is cent	e vehicle ke one o side ope back.	es pop loo e back of e you car of the bille secure bi	n now insta e longer b illet grilles a e longer b	move the y grille ar all the fo nd place illets go using the	grille , if t d pressin ur billet gu it into the n the top toggle nu	Fig 3	the factory opening in openings).	a can use a flat e screwdriver while grille on a workbench the factory grille ( the Turn the factory grille

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!