



# PATENT PRODUCT


## Grille Installation Instruction

Rev. 190101

<b>Part#</b>	GR06FFJ11 C/S/J	<b>Application</b>	For 1999-2004 Ford Mustang V6 Hood (Scoop Below Hood)
--------------	--------------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	1	Billet Grille	1	Stainless steel	3	Screws	2	8# × 1"
	2	Clip Nuts	2	8#				

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Center the billet into the opening, and mark both mounting holes in the opening. Drill holes at each mark.	
4	Insert a screw at each tab and fasten with a clip nut from the rear. Now tighten the screws.	
5	Make sure the insert is centered over the bumper opening. It may be necessary to slightly bend the brackets on the insert to get a perfect fit.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!