



| | | | |
|-------|------------|-------------|---|
| Part# | GR06FFJ12C | Application | For 05~09 Ford Mustang V6 (1PC) – Billet Grille |
|-------|------------|-------------|---|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|------------------|-----|-----------------|------|-------------------|-----|-------------|
| | 1 | Billet Grille | 1 | Stainless steel | 4 | Truss Head Screws | 2 | 6-32×1.5" |
| | 2 | Washers | 4 | 6# | 5 | Truss Head Screws | 2 | 6-32×2" |
| | 3 | "J"Hook Brackets | 4 | | 6 | Nylon Lock Nuts | 4 | 6-32 |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|--|---|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Remove the plastic radiator cover from the vehicle; Remove the Mustang logo from the grille. Test fit the billet over the factory grille. Insert a 1.5" machine screw (the shorter screws provided) into the upper tabs on the insert. From the back of the insert, slide a J hook, washer and lock nut onto the screws (only thread the nuts by hand at this time). Repeat this process on the lower tabs with the 2" machine screws. |  |
| 3 | Center the billet over the factory grille. The J hook brackets hold the billet to the honeycomb area in the grille. | N/A |
| 4 | Make sure the hooks wrap around the honeycomb mesh; now use a Phillips screwdriver and 5/16 wrench to snug the hardware down until the billet is held firmly in place. | N/A |
| 5 | Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten. | N/A |
| 6 | Re-install the plastic radiator cover. Use a high quality double-sided tape to secure the factory Mustang logo to the billet insert if desired. | N/A |
| 7 | Installation completed!!! | N/A |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!