

Grille Installation Instruction

Rev. 150116

Part# GR06FFJ13A Application 05~09 Ford Mustang GT V8 (3pcs)

| | | Item | Part Nan | ne QTY | Descri | otion | Item | Part Name | QTY | Description | |
|------------------------|---|----------------------------------|--|---|--|--------|----------------|-------------------|-----|-------------|--|
| Parts Li | ct | 1 | 1 Billet Grille | | 1 Aluminum | | 4 | Washers | 8 | 6# | |
| Fails LI | ο ι | 2 | 2 Lock Nuts | | 8 6-32 | | 5 | Truss Head Screws | 8 | 6-32×2″ | |
| | | 3 | 'J' Hooks | s 4 | | | | | | | |
| Install Notes: Overlay | | | | | | | Drill Cut × | | | | |
| Step | Description | | | | | | illustration | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | | | | | | |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | | | | | | | | | | |
| 3 | Ren the mou deg | nove the billets inting free and | ne plastic radia ne Mustang lo over the f tabs have 1/2 gle. The side ne center billet. | go from the gattory grille. " spacers b | grille. Test fi The lowe ent at a 90 | t r | | | | | |
| 5 | Mark the mounting tabs on the side billets to the plastic grille. Drill a 1/8" hole at each mark; Use the screws, washers and nuts to secure the billets. Do not over-tighten. | | | | | | | | | | |
| 6 | Insert the screws into the tabs on the center insert. From the back of the insert, slide on the J hooks and washers; hand tread the lock nuts. Make sure the hooks wrap around the honeycomb mesh. Snug the hardware down until the billet is held firmly in place. | | | | | | | | | | |
| | Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten. | | | | | N/A | N/A | | | | |
| | Reinstall the black plastic cover which was removed in step 2. | | | | | | N/A | | | | |
| 9 | Installation completed!!! | | | | | | | | | | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!