


| | | | |
|-------|------------|-------------|----------------------------------|
| Part# | GR06FFJ13J | Application | For 2005-2009 Ford Mustang GT V8 |
|-------|------------|-------------|----------------------------------|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-----------------|------|-------------------|-----|-------------|
| | 1 | Billet Grille | 1 | Stainless steel | 4 | Washers | 8 | 6 # |
| | 2 | Lock Nuts | 8 | 6-32 | 5 | Truss Head Screws | 8 | 6-32 × 2" |
| | 3 | 'J' Hooks | 4 | | | | | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|--|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | N/A |
| 3 | Remove the plastic radiator cover from the vehicle; Remove the Mustang logo from the grille. Test fit the billets over the factory grille. The lower mounting tabs have 1/2" spacers bent at a 90 degree angle. The side billet will only fit one way. Remove the center billet. | N/A |
| 5 | Mark the mounting tabs on the side billets to the plastic grille. Drill a 1/8" hole at each mark; Use the screws, washers and nuts to secure the billets. Do not over-tighten. | N/A |
| 6 | Insert the screws into the tabs on the center insert. From the back of the insert, slide on the J hooks and washers; hand tread the lock nuts. Make sure the hooks wrap around the honeycomb mesh. Snug the hardware down until the billet is held firmly in place. | N/A |
| 7 | Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten. | N/A |
| 8 | Reinstall the black plastic cover which was removed in step 2. | N/A |
| 9 | Installation completed!!! | N/A |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!