




Grille Installation Instruction

Rev. 191001

Part#	GR06FFJ20 A/H	<i>Application</i>	For 1999-2004 Ford Mustang GT V8 Hood (Scoop Above Hood)
--------------	--------------------------	--------------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	2	Truss Socket Tapping Screws	2	8×1"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood of the vehicle, and remove the grille shell from the vehicle.	
3	Take out the factory billet grille and hardware from the package. You must be care of doing this for protect the surface of the factory grille.	
4	Center the factory grille into the opening of the shell. Mark the position of the nuts welded the grille rear and drill in the plastic .Then thread the screws into the nuts by a knurl wrench. Place the screws through the holes drilled and fasten it using the kep nuts and flat washers.	
5	Be sure the grille is centered, tighten all the hardware but do not over-tighten	
6	Re-install the grille shell onto the vehicle.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!