





Grille Installation Instruction

Rev. 190601

Part#	GR06FFJ22A/H	Application	For 2005-2009 Ford Mustang V6 With Logo Show
-------	---------------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	4	Truss Head Screws	2	6-32x2"
	2	Nylon Lock Nuts	4	6-32	5	'J' Hook Brackets	4	
	3	Washers	4		6	Truss Head Screws	2	6-32x1.5"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. Remove the Mustang logo from the grille.	
3	Test fit the billet over the factory grille. Insert a 1.5" screw (the shorter screws provided) into the upper tabs on the insert. From the back of the insert, slide a J hook, washer and lock nut onto the screws (only thread the nuts by hand at this time). Repeat this process on the lower tabs with the 2" screws.	
		
4	Center the billet over the factory grille. The J hook brackets hold the billet to the honeycomb area in the grille. Make sure the hooks wrap around the honeycomb mesh; now use a Phillips screwdriver and 5/16 wrench to snug the hardware down until the billet is held firmly in place. Re-install the plastic radiator cover. Use a high quality double-sided tape to secure the factory Mustang logo to the billet insert if desired.	
5	Reinstall the black plastic cover which was removed in step 2.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!