A	PS
AUTO PARTS SPECIAL	IST INC.

Grille Installation Instruction

Part#	Gł	R06GI	EC27H	Applic	ation	08-10 Ford F250/F350 Pickup – Stainless Steel Mesh Grille					
		ltem	m Part Name QTY		Description Item		ltem	Part Name	QTY	Description	
Parts L	ict	1 Mesh Gri		rille	6	Stainless st	eel	4	2-Hole Tabs (Long)	8	
	.151	2 Screws			22	6-32×1″		5	2-Hole Tabs (Short)	6	
		3 K-Lock Nuts			22	6-32					
Install Notes: Overlay \checkmark Replacement \times							D	orill ×	Cut ×		
Step	Description					illustration					
1	Identify the grille & hardware with parts list.							()		
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.										
	Secure the stud to the threaded holes on the rear of the grille.										
3	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.										
4	Secure grille using the lock nuts from the back side of the OEM grille shell.					N/A					
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.					N/A					
6	Reinstall the black plastic cover which was removed in step 2.					N/A					
7	Installation completed!!!					N/A					

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!