	PS
AUTO PARTS SPECIA	

Grille Installation Instruction

Part#	GR06GEG84T Application 08~10 F Grille							Ford Escape – Bumper Stainless Steel Mesh						
		ltem	Part Name		QTY	Descript		tion Item		n	Part Name		QTY	Description
Parts L	ict	1	Mesh G	rille	e 1		Stainless st		4		Nylon Lock Nuts		4	6-32
Faits L	.151	2	Screws		4		6-32×2 ″		5		Washers		4	
		3	2-Hole	Tabs	2									
Install Notes: Overlay \checkmark Replacement \times							C	Drill	×	Cut	×			
Step	Description							illustration						
1	Identify the grille & hardware with parts list. Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow							N/A						
3	access to the rear of the grille shell. Thread a screw in each nut welded to the grille. From the rear, place a tab on each screw. Now thread a nut on each screw.							N/A						
4	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.													
5	Reinstall the black plastic cover which was removed in step 2.							N/A						
6	Installation completed!!!							N/A						

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!