


Part#	GR06GFH29G	Application	For 2011-2016 Ford F-250 / F-350 / F-450 SD All Model
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	2	Super Duty Custom Brackets	2	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Remove the 2 bolts on the outer edges in the factory bumper opening.	N/A
4	From underneath the vehicle, take the bumper mesh and insert it from behind the bumper into the factory bumper opening.	N/A
5	While holding the bumper mesh up against the inside of the bumper, take the two brackets that came in the hardware bag and the bolts you removed from the factory bumper and insert them through the end of the bracket with the hole in it. The end of the bracket with a small notch in it will	N/A
6	Make sure the grille is centered and tighten the fasteners. but do not over-tighten.	N/A
7	Reinstall the black plastic cover which was removed in step 2.	N/A
8	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!