



# PATENT PRODUCT


## Grille Installation Instruction

Rev. 180701

<b>Part#</b>	GR06HEB48C/J	<b>Application</b>	<b>For 1967-1968 Ford Mustang</b>
--------------	--------------	--------------------	-----------------------------------

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	1	Billet Grille	1	Stainless steel	3	Studs	2	1/4-20UNC × 3/4"
	2	Nut	2	1/4-20UNC	4	Two hole tabs	2	

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Attach the studs to the backside of the billet grilles and then fit billet grille on to the grille shell.	N/A
4	Once the billet grilles have been centered to your liking, then attach the black powder coated rackets to the studs that come through the backside of the grille shell and secure with the nuts provided.	N/A
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Once the billet grilles have been firmly secured, re-attach the grille shell with your new billet grille back to the vehicle.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!