

| | | | |
|--------------|------------|--------------------|---|
| Part# | GR06HED35J | Application | For 2001-2003 Ford Ranger 2WD/Not For Edge Model |
|--------------|------------|--------------------|---|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|-------------------|------|---------------|-----|-----------------|------|-----------|-----|---------------|
| | 1 | Billet Grille | 1 | Stainless steel | 4 | Nuts | 2 | 1/4" -20 |
| | 2 | Lock Washers | 2 | 1/4" | 5 | Hex Bolts | 2 | 1/4" -20x3/4" |
| | 3 | Flat Washers | 2 | 1/4" | | | | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | N/A |
| 3 | Place the billet insert in the bumper / air dam opening. There should be two holes in the bumper opening that line up with the two mounts in back of the billet insert. | N/A |
| 4 | Center the billet in the bumper opening. Fasten the billet insert to the factory holes using the hardware supplied. | N/A |
| 5 | Secure billet grille using the nuts from the back side of the OEM grille shell. | N/A |
| 6 | Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten. | N/A |
| 7 | Reinstall the black plastic cover which was removed in step 2. | N/A |
| 8 | Installation completed!!! | N/A |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!