

Grille Installation Instruction

Rev. 190901

Part#	GR06HEJ09T/U		J Ap	plication	For 198	For 1987-1991 Ford Bronco /F-150 / F-250 / F-350				
	Item	Part Name	QTY	Descri	ption	Item	Part Name	QTY	Description	
Parts List	1	Billet Grille	1	Aluminum		5	Safety Release Lever Extension	1		
	2	U-Clip Nuts	8	10#		6	Truss Socket Tapping Screws	8	10×1″	
	3	Hex Bolts	2	1/4" -20×3/4"		7	Washers	4		
	4	Kep Nuts 2		1/4" ×20						
Install I	Notes:	Overlay	×	Replacement \[D	Drill $\sqrt{}$ Cut \times			
Step	Description						illustration			
1	Identify the grille & hardware with parts list.								2	
2	Remove plastic shroud between top of grille and radiator support. Retain all mounting fasteners.									
3	Remove factory grille									
4	Attach safety release extension to safety release lever by drilling lever in two places with 1/4" drill. Then bolt extension in place using two 1/4-20 bolts provided. Safety release extension must not be higher than radiator support.									
5	Paint radiator and radiator support with flat or semi-gloss black paint. Hood Latch								d Latch	
6	Place two of the black U-clip nuts on the core support where the two center mounting tabs of the factory grille attach. Safety Release Extension									
7	Place two of the black U-clip nuts on the core support where the two bottom tabs of the factory grille mount.									
8	Place the remaining four black U-clip nuts on the top four tabs of the grille.								ase lever	
9	Center the grille in the opening and attach the four tabs of the grille to the plastic shroud. Attach the remaining four tabs with the factory grille screws.									
10	Make	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.								
11	Reinst	Reinstall the black plastic cover which was removed in step 2.								
12	Install	Installation completed!!!								

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!