

Grille Installation Instruction

Rev. 150116

Part#	GR06HEJ85C		For 99~03 Ford F-150 4WD / Expedition 4WD Low				
			Bumper – No Cut				

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description	
Parts List	1	Billet Grille	1	1 Stainless steel		Truss Socket Tapping Screws	6	8#×3/4"	
	2	Flat Nut	6	8#					
Install Nation Constant [2] Boules among [2] Boile [2]									

Install	Notes: Overla	y	Replaceme	nt ×	Drill		Cut	×			
Step	Step Description						illustration				
1	Identify the grille	N/A									
2	Pop hood, remo OEM grille / fron access to the re										
3	To install F850 delete the front retain it, unsnap and lift it out of clips from the retaining rivets a	N/A									
4	Put the grille over the opening from the front. Center it and mark the six places where the holes are in the tabs of the billet grille.				N/A						
5	Drill the six holes with a 1/8" drill bit.				N/A						
6	Attach with the six screws and flat nuts provided in the installation kit. Access to the backside of the factory bumper valance can be achieved by removal of the rubber air shield at the bottom of the bumper or removal of the upper grille shell assembly at the top while installing the upper billet grille.				N/A						
7	Installation completed!!!				N/A						

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!