	AUTO PA	ARTS SPECIALIS	ST INC.		Grille	Insta	allation Instr	uctio	n	R	ev. 150116	
Part#	GR06HEJ99H Application 99-			99-04	04 Ford:F-250/F-350/F-450/ F-550 Super Duty / Excursion							
Parts L	.ist	<b>Item</b> 1 2	Billet Gri		me ing Screws	<b>QTY</b> 1 5	Description Aluminum 10×3/4 "	ltem 3	Part Name Flat Nuts	<b>QTY</b> 5	Description 10#	
Install I	Note	es: 0\	verlay	×	Replacem	ent	<b>Drill</b> $$ <b>Cut</b> $$					
Step	Instruction						Photo				Note	
1	Remove factory grille shell from truck. Place grille shell on blanket to help protect from scratching or damaging chrome finish. Note accent line on grille shown in Use a scoring blade and score line as shown (Figure 1) to eliminate chrome peeling.											
2	<ol> <li>Using a cutting tool (die grinder, air saw, razor knife, saber saw) carefully cut out the three center sections. See Figure 2</li> </ol>						Figure 2			arg colo	Cut only the argent (gray colored) portion of grille.	
	② You may also cut out the grille shell for one full opening. See Figure 3.						G	Figure	5			
	<ul> <li>③ Smooth out the cut surface with a flat file a grinding tool. See Figure 4 – 7.</li> <li>You must leave the tabs shown in figure 5 &amp; 9 in order to install</li> </ul>					ure	Figure 4	4	Tab on she	No. Sol And		
		<u>the b</u>	illet grille	<u>le.</u>	<u>}.</u>		<u>Figure</u>	<u>6</u>	<u>Fi</u>	gure 7		
The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!												

Part#	GR06HEJ99H Application	99-04 Ford : F-250/F-350/F-450/ F-550 Super Duty / Excursion					
Step	Instruction	Photo Note					
3	Place the billet grille into the gr shell, center the grille for prop fitment. You may need to bend slight radius into the billet grille. To this, face the billet grille away fro you. Next place your hands arou the billet grille with your thumbs in the U-Channel push the forward.	N/A					
4	Once the grille is adjusted for the be fitment, place the grille back into f grille shell. Mark and drill the fo lower mounting points of the gri securing the two outside brack first. See Figure 7 and 8.	he bur le, ets Figure 8					
5	Next, push down on the billet gr until it sits flush into the grille sh then mark and drill your two upp mounting points. You will need to u a very short screw driver to between the grille and the grille she	ell, ber se fit N/A Installation is now complete!					
	<u>3 Openings</u>	Full Opening					

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!