

PATENT PRODUCT Grille Installation Instruction

Rev. 180301

-	AUTO PAI	RTS SPECIAL	IST INC.					stai	an		SILUCTION				Rev. 180301
Part#		GR	06HFD	14S	Application		/	For 2009-2014 Ford F-150 Not For Harley Davidson And Raptor							avidson And
		ltem	Pai	rt Nar	me	QTY	Des	cript	ion	ltem	Part Nam	e	QTY		Description
Parts L	-	1	Billet Grille			1	Stainless ste			4	M-Screw		2	6#×1	1/2"
	IST	2	Screw			6 10#				5	Lock nut		2	6#	
		3 Flat Nut				6	10#	0#			Flange Brack	ets	2	/	
Install N	stall Notes: Overlay X Replacement $$ Drill $$ Cut $$														
Step	Description								illustration						
1	Identify the grille & hardware with parts list.														
2	Remove 6 Bolts along the top of the Grille Shell.(Fig.1) Remove 2 Clips along the Vehicle Support Bar.(Fig.2) Place the Plastic Pry-bar in between the Grille Shell and Hood ,Firmly start nudging away the Grill Shell from the Hood.(the Grille Shell is latched on with Clips).(Fig.3)														
	$\begin{tabular}{ c c c c c c } \hline \hline Fig 1 \end{tabular} \end{tabular} \begin{tabular}{ c c c c c c c c } \hline \hline Fig 2 \end{tabular} \end{tabular} \end{tabular} \end{tabular} \end{tabular} \begin{tabular}{ c c c c c c c c c c c c c c c c c c c$														
3	With a Die Grinder, Remove the Vertical and Horizontal Plastic Bars that are around the Grille. (Fig. 4 & 5)														
4	Center billet grille in backside of grille shell.Place the Grille into the Grille Opening. (Fig. 6)														

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.



PATENT PRODUCT Grille Installation Instruction

Rev. 180301

Part#		F86414C/J	Application	For 2009-2014 Ford F-150 Not For Harley Davidson And Raptor				
5	place with the t	the 3/16 Drill,Drill e the #10 Screws a Flat nut. (Fig. 7) F wo inner Brackets ge Brackets and Th 8)	through them Place the M-Screw that are on the 0	Threading s through Grille, the				
6	Make sure the billet grille is centered and tighten the fasteners.							
7	Insta	llation completed!!!						

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.