


Part#	GR06IEC33 A/H	<i>Application</i>	For 2000-2003 Ford Windstar Not For Limited
--------------	------------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Aluminum	3	Studs	4	6-32 × 1.5"
	2	Flat Tabs	4		4	K-Lock Nuts	4	6-32

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.	
3	Thread a stud in each nut welded to the grille.	
4	From the rear, place a tab on each screw. Now thread a nut on each screw.	
5	Make sure the insert is centered and tighten the hardware.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!