

4

5

6

7

8

9

10

Installation completed!!!

Insert billet grille from front on the opening of factory shell.

Reinstall the black plastic cover which was removed in step 2.

Push stud past through honeycomb of factory grille.

Grille Installation Instruction

Rev. 180801

Part#	GR06IEC41A/H			Application		n For	For 2006-2010 Ford Explorer							
		Item	Part Nam	ne	QTY	Description		Item	Part Name		QTY	Description		
Parts Li	ist	1	Billet Grille		1	Aluminum		4	Studs			4	10-24 X 1.5"	
		2	Kept Nuts		4	10-24		5	"S" hooks tabs			4		
Install Notes: Overlay Replacement							× [Orill	×	Cut	×			
Step	Description						illustration							
1	Identify the grille & hardware with parts list.						****							
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.													
3	Screw bolts inside the hole behind of billet grille.													

Place the tabs provided behind over the factory shell bar, let the stud through after washers and nuts.

Adjust stud position to make sure the grille is in the center of opening. Tighten but be careful of over-tighten.

Repeat step 6 above for each stud until the billet grille lie over the factory shell.

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!