
















Part#	GR06LEI91K	Application	2009-2014 FORD RAPTOR SVT					
Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	5	Mounting Plate A	1	/
	2	Lock Nut	11	6-32	6	Mounting Plate B	1	/
	3	Washer	6	6-32	7	Plastic Clip(AV14738)	1	/
4	C-Brackets	3	/	8	Plastic Clip(AV13198)	1	/	

Install Notes: Overlay Replacement Drill Cut

Installation

 <p>1. Identify the grille & hardware with parts list.</p>	 <p>2. Unclip Cable that connects the Lights and Camera on the Grille (On Drivers Side of Factory Grille). (Fig. 1)</p>	 <p>3. Remove 8 10mm Bolts (6 along the Top of Factory Grille and 2 on the Vertical Bars).(Fig. 2)</p>
 <p>4. To Remove the Grille, Pull Outward on the Grille and go Down. (Fig. 3)</p>	 <p>5. Remove Grille. Remove 6 Bolts on the Black Bar along the Bottom of the Factory Grille and remove. (Fig. 4)</p>	 <p>6. Unscrew the 2 Nuts that are on the Lights along the top of the grille and Remove a Clip that holds the Light in Place, Remove Remaining Lights. Insert the Lights onto the Mesh Grille, Insert a C-Bracket to hold the Light in Place and Thread a 6/32 Nylon Lock Nut (Repeat for other 2 Lights). (Fig. 5)</p>
 <p>7. Reinstall the Black Bar along the bottom of the Mesh Grille. (Fig. 6)</p>	 <p>8. Insert washers and Thread 6/32 Nylon Lock Nuts on the Threaded Studs. (Fig. 7)</p>	 <p>9. Remove the 2 Screws that are on the Camera Housing and Remove the Housing and Camera. (Fig. 8)</p>

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Part#	GR06LEI91K	Application	2009-2014 FORD RAPTOR SVT
 <p>10. Unscrew the 2 Nylon Lock Nuts that are behind the Logo. (Fig. 9)</p>	 <p>11. Use the Provided Mounting Plate (either Mounting Plate for Camera or Mounting Plate without Camera depending on your Vehicle) and Drill through the Holes that are on the Mounting Plate to the Camera Housing. (Fig. 10)</p>	 <p>12. Place Mounting Plate on the Threaded Screws on the Logo and Thread back in the Nylon Lock Nuts. (Fig. 11)</p>	
 <p>13. Place the Camera Housing on top of the Mounting Plate and Thread Nylon Lock Nuts in Place. (Fig.12)</p>	 <p>14. Place the Camera back into the Housing. (Fig. 13)</p>	 <p>15. Place back the Plastic Cover and Thread back in the Screws. (Fig. 14)</p>	
<p>16. Place the Mesh Grille onto the Grille Opening and Thread back in the 8 10mm Factory Bolts.</p>	<p>17. Place the 2 (or 1) Small Plastic Clips through the Holes that Located in Front of the Logo (Depending on Which Template you used).</p>	<p>18. Installation completed!!!</p>	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!