

Г

Grille Installation Instruction

Τ

Part#	GR07FEA49A Application 07-10 G					MC Acadia Main Upper						
		Item	Part Name		QTY	Descriptio		ltem	Part Name	QTY	Description	
Parts L	.ist	1 Bille		Grille	1	Aluminum		3	Screws	4	8# × 1 ″	
		2	U-Clip Nut		4	8#						
Install Notes: Overlay 🔨 Replacement 🗵								orill ×	Cut √			
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Pop hood, remove the OEM grille from vehicle according to the vehicle user menu.											
3	Remove the emblem from the OEM grille, and cut off the emblem base on the OEM grille.											
4	Center the billet grille onto the OEM grille. insert the screws into the weld tab							Contraction of the second				
5	Secure the grille using the U- Clip Nuts from the back side of the OEM grille shell.							(4) 8#x1" screws (4) 8# U-clips				
6	6 Make sure the grille is centered and tighten all fasteners. Reinstall the OEM grille onto the vehicle with the billet grille											
7	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!